Epson perfection v700 photo scanner manual

I'm not robot
reCAPTCHA
Continue

Este Guide usuario es el handmade en pantalla de su escaner EPSON Perfection V700/V750 Photo. Haga clic en uno de los siguientes temas para empezar. The features and specifications of the product can be modified without notice. 6400 DPI (Horizontal x Vertical) Basic 6400 DPI x Sub 9600 DPI 216 mm x 297 mm (Horizontal x Vertical) Entry: 48 Bits Colour, Exit: 48 Bits Color Cold Cathode Fluorescence Lamp Fixed Documents and Moving Carriage 50'6400 (1 dpi step), 9600, 12800 DPI Monochrome: 11 s/page - Color: 14 s/page measured with size A4, Resolution 300 dpi,, Color: 25 s/page measured with size A4, Resolution 600 dpi , 35mm positive film, 2400dpi: 44 s - best, film 35mm negative, 35mm positive film. 2400dpi: 47 s - Best 35mm film strip: 4 x 6 frames, 35mm mounted film: 12 frames, 120/220 Medium format (Max. 6 x 20cm): 2 frames, 5 x 4 inches: 2 frames, 203 x 254 mm when using film guidance , Dust Removal, Print Images Compliance II, De-screening with pattern optimization, Correction of tonal value with histogram, Color Palette Tool for Easy Color Fix, Lighting Correction, Color Recovery, Unsharp Mask with Noise Crusher, De-screening with document-type optimizer, ICE Digital Technology (for film and photo) AC 220 V - 240 V, 50 Hz - 60 Hz 32 Watts (operation), 19 watts (Ready), 4 watts (sleep mode) 503 x 308 x 152 mm (width x Depth x Height) Adobe® Photoshop 10 SilverFast SE 8 Mac OS 10.5.8 or later, Windows 7, Windows 8, Windows Vista, Windows XP, Windows XP x64 Operation 10% - 80%, Storage 10% - 85% Operation 5 C - 35 C, Storage -25 C - 60 C Proof sign-off:R4CG090 ChrisStart Here Rev CMs. Araki Veronicas_SH.indd A2 sizeArlyn10/26/05Start here Point de de Partinstall Software® ®® ®Epson Perfection V700 Photo/V750 ProEpson Perfection V700 Photo/V750 ProInstallation des logiciels41 2UnpackD'ballage1Insert CD software scanner. Inceres le CD de logiciels de V700 photonumerization dans le lecturer. Click on English, click Continue, and then click Agreed. Click Set and follow the V750 Proon-screen instructions. In Resumen del contenido incluido en la p'gina 2 Proof sign-off: R4CG090 Chris Start Here Rev. C Ms. Araki Veronicas_SH.indd A2 size Arlyn 10/26/05 Beginning here Point de de installation software ® ® ® ® Epson Perfection V700 Photo / V750 Pro Epson Perfection V700 Photo / V750 Pro Installation des logiciels 4 1 2 Unpack D'ballage 1 Insert Software Scanner CD. Inseres le CD de logiciels de V700 photo numbering dans le lecturer. Click on English, click Continue, and then click Agreed. Click Set and follow the V750 Pro instructions on the screen. In Resumen del contenido incluido en la pegina 3 Proof sign-off: Chris Start Here Reverend C Ms. Araki Veronicas_SH.indd A2 size Arlene 10/26/05 Color Recovery Restoration de la Cooler Scan Photo 1 2 Numerization d'une 6 1 2 3 Remove dust from the film/slides Depussiaz de band de film/diapositives 1 2 Click Start. Appeis sur le Boton Demarrer. 6 4 5TM Remove dust or scratch marks using DIGITAL ICE Technology or DIGITAL ICE Lite Technologies MC MC D'pouussi'rage ou 'lymination des rayures et l'aide de la technolo Rememen del Contenido incluido en la Pagina 4 Proof sign-off: R4CG090 Chris Start Here Rev. C Ms. Araki Veronicas_SH.indd A2 size Arlene 10/26/05 Color Restoration Color Restoration Restauratia de la Cooler Scan Photo 1 2 Numerization d'une Photo 6 1 2 3 Remove dust from the film/slides Dupussierat de strips de film / diaposititives 1 button Click Start. Appeis sur le Boton Demarrer. 6 4 5TMM Remove dust or scratches using DIGITAL ICE or DIGITAL ICE Lite Technology MC D'gos'sage ou slimination des rayures - l'aide de la technolo Epson Perfection V 70 Photo/V750 Pro 12/05 Epson Perfection V700 Photo/V750 Pro - 1 Scanner Parts Note: Epson Perfection V750 Pro also includes a liquid-mounted tray. Scanner Specifications General Document Table Carriage and Lamp (At Home)Page 2 Epson Perfection V700 Photo / V750 Pro 2 - Epson Perfection V700 Photo / V750 Pro 12/05 Mechanical Electric Note: Check the label on the AC adapter or on the back of the scanner for voltage information. Scanner AC Adapter Environmental Interfaces USB Interface FireWire Interface Standards and Approval Scanner AC Adapter Scanning Speed V700 Photo: approximately 12.3 msec per line at 4800 dpiV750 Pro: approximately 11.8 msec per line at 4800 dpiApproximately 1 3.1 msec per line on 600 dpiPage 3 Epson Perfection V700 Photo/V750 Pro 12/05 Epson Perfection V700 Photo/V750 Pro - 3 Scan document or photos Before scanning the document, do not forget to respect the rights of rights holders. Don't scan published text or images without one checking their copyright status. Page 4 Epson Perfection V700 Photo/V750 Pro 4 - Epson Perfection V700 Photo/V750 Pro 12/05 3. Open the scanner cover. 4. Lift the scanner cover straight up and off the scanner. 5. Turn on the scanner with the P. Note: When scanning without a scanner lid, gently press the document to smooth it out. 6. When you're done scanning, replace the scanner cover in reverse order that you've removed it. Scan film and slides Removal of the document mat To scan the film strips or slides, you need to remove the document mat from the cover of the scanner. This reveals the transparency unit so your scanner can use it to scan film or slides. Page 5 Epson Perfection V700 Photo/V750 Pro 12/05 Epson Perfection V700 Photo/V750 Pro - 5 3. Use a soft cloth to wipe the transparency block window and document table before placing the film or slide. Place the film or slides to scan, see the sections below. Placing the film in the holder Placing 35 mm film strip 1. Remove Delete film strip cover (s) on the film holder. 2. Slide to four strips of film down to the film holder with a shiny base face down. Your images and any formulation on the film strips should be displayed backwards on the side that stands up, as shown in the illustration on the film holder. Page 6 Epson Perfection V700 Photo/V750 Pro 6 - Epson Perfection V700 Photo/V750 Pro 12/05 Side, which stands up, as shown in the illustration on the film holder. Make sure the entire frame of the image is located in the opening of the film holder. Note: Keep the edge of the film gently or use gloves to touch the film; Otherwise you can damage the film. Make sure the white stickers on the back of the film holder and the area around them are not scratched, dusty, or covered in any way. If the areas are hidden, the scanner may have trouble recognizing your movie in Full Auto mode. Do not cover any of the tiny holes in the film holder or scanner may have a problem with recognizing which film holder you are using. 3. Close the lid over the film and press it down until it clicks. Then press down on all edges of the lid to secure it. 4. Place the film holder on the document table so that it is aligned with the top right angle and the pins sit in the holes on the scanner. 5. Make sure you remove the document mat. See The Removal of the Document Mat on page 4. 6. Close the scanner cover. Note: You can't use Full Auto Mode to scan mid-format film. When you're done scanning the film, be sure to replace the document mat before scanning documents or photos. See Replacement Document Mat on page 9. Accommodation 4 × 5 inches Movie 1. Open the lids on a 4-inch × 5-inch film. 2. Place the film in the film holder with a shiny base face down. Your images and any formulation on the film should be displayed backwards on the side that stands up, as shown in the illustration on the film holder. Make sure the entire frame of the image is located in the opening of the film holder. Note: Keep the edge of the film gently or use gloves to touch the film; Otherwise you can damage the film. Make sure the white stickers on the back of the film holder and the area around them are not scratched, dusty, or covered in any way. If the areas are hidden, the scanner may have trouble recognizing your movie in Full Auto mode. Do not cover any of the tiny holes in the film holder or scanner may have a problem with recognizing which film holder you are using. 3. Close the lid over the film and press it down until it clicks. Then press down on all edges of the lid to secure it. ENENNLDEFRPage 2 ENENNLDEFRPage 3 ENENNLDEFR 1 2 3 4 5 6 7 8 9 10 Table Contents 11 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 36 3637 38 39 40 41 42 43 44 45 46 48 49 50 51 52 53 54 55 56 56 5 7 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 80 82 83 84 85 86 87 88 89 90 91 92 93 94 96 97 98 99 100 101 102 103 10 4 4 4 4 4 4 4 4 4105 106 107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 12 12 12 12 12 12 122 123 124 125 126 127 128 129 130 131 132 133 134 135 136 137 138 139 139 14 141 142 143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 Epson , Perfection, Guide, Scan, Scan, Digital, Auto, Edition, Technologytm, Specs, Mypdfmanuals.com User Guide EPSON PERFECTION V700 PHOTO - 1 - MY PDF.....

normal_5f8a679879c6e.pdf
normal_5f88b409f3a92.pdf
normal_5f8f2a17b59d5.pdf
normal_5f8e099488b68.pdf
emanuel swedenborg pdf deutsch
enigma otiliei pdf scribd
sny training celulites estrias realm
download dorian gray study guide
pen and ink drawing a simple guide f
tactical radio quick reference guide
free minecraft games for android tablet
yodlee moneycenter android app
baixar azeitona livro pdf
android studio change file name
building automation system design pdf
la masse volumique cours pdf
msi z390 ace motherboard manual
emission spectra and energy levels worksheet
oral anatomy embryology and histology pdf
normal_5f8c892a9ef0f.pdf
normal_5f8f22f010846.pdf
normal_5f89caa1c950d.pdf