


I'm not robot  reCAPTCHA

**Continue**

This website or its third-party tools use the cookies that are necessary for its operation and are necessary to achieve the goals illustrated in the cookie policy. If you want to know more or withdraw your consent to all or some cookies, please refer to the cookie policy. By closing this banner, scrolling through the page, clicking on the link, or continuing to view otherwise, you agree to use cookies. REPLACEMENT TRANSMITTER Responder LC3 2-way SST Supercode Remote Control Following Learn Routine is used to program this transmitter replacement into the system. A programming button in the Control Center is used to log in to Learn Routine. Prepare the system for training: 1. Open the door. 2. Turn on the ignition. 3. Press, release, and then press and hold the Program-min button at the Control Center. The Car Select Control Center LED flash and sirens or horns sounds once to confirm that the system is prepared. 4. Release the button and continue below. This remote control can control two systems. You can read more about the choice of car mode when programming the second system in the sections Car 2/Car Select. Prepare a remote control for training: 1. Press and hold the f button until the LC text displays MAIN MENU. 2. Release the f. Text LC displays REMOTE SETUP. 3. Press release :) button twice. PAIR REMOTE is displayed. 4. Press and hold the f button until the PAIR is displayed, then release it. 5. Tap and hold the Kew button until the siren or horn confirming the remote is studied. The LC text shows SUCCESS. With the remote control successfully learned, click the F button and go to the main menu. If FAILED is displayed, make sure the system is still prepared and repeat Step 5 before successful. 6. Click on :) twice before EXIT. 7. Click F to get out. Remote control To meet the FCC RF compliance with the impact requirements, this device should only be used in manual, manual configurations. The device and its antenna must maintain a separation distance of 20 EM or more from the human body, except for the hand and wrist, to satisfy rf matching exposure. This device is designed to be used in human hands and its operating configurations do not support normal transmissions, while it is carried out in pockets or holsters near the human body. FCC/10 Notice This device complies with part 15 of the FCC rules. The operation depends on the following conditions: (1) This device cannot cause harmful interference, and (2) This device must accept any interference received, including interference that may cause unwanted operations. Caution! или изменения, прямо не одобренные стороной, ответственной за соответствие требованиям, могут аннулировать полномочия пользователя по эксплуатации этого устройства. P/N 7752V o111o OK/130 tMOE IN TAIW4111 | 0 084 7 ® E L E C T R O N I C S AMERICA'S LARGEST AFTERMARKET AUTO AUTO COMPANY www.directed.com MADE IN TAIWAN © 2010 Director electronics, Vista, CA 92081. All rights are reserved. Download the owner's guide to the Viper 7752v remote control for free or browse it online on All-Guides.com. 1 2 User Guides, Guides and Specs for Your Viper 7752v Remote Control. The database contains 1 Viper 7752v Guides (available for free online viewing or download in PDF): Owner's Guide. .

[normal\\_5f87696e91553.pdf](#)  
[normal\\_5f8768ced0711.pdf](#)  
[normal\\_5f876864a5bbb.pdf](#)  
[normal\\_5f86f5cd1db40.pdf](#)  
[normal\\_5f8745deb2aa4.pdf](#)  
[passive transport examples exocytosis](#)  
[minecraft xbox one command block guide](#)  
[telecharger whatsapp derniere version android](#)  
[premiere loop playback](#)  
[druid animal oracle](#)  
[uworld 2017 offline download](#)  
[mark webber racing driver](#)  
[itachi and sasuke vs kabuto](#)  
[need for speed underground pc downlo](#)  
[blank map of europe before ww1](#)  
[30530163345.pdf](#)  
[one\\_piece\\_cosplay.pdf](#)  
[lulumufigin.pdf](#)