


Hampton bay wireless doorbell extender instructions

 I'm not robot  reCAPTCHA

Continue

Item #1001411385 model #HB-7902-02 USE AND CARE GUIDE WIRELESS DOORBELL EXTENDER KIT Issues, Problems, Missing Parts? Before returning to the store, call Hampton Bay Customer Service from 8 a.m. to 5 p.m., CST, Monday through Friday 1-844-760-3644 HAMPTONBAY.COM Illustrations may differ from the actual unit. THANK YOU We appreciate the trust and confidence that you have placed in Hampton Bay through the purchase of this wireless doorbell extension cord kit. Table content Table Content..... 2 Security information..... 2 Guarantee..... 2 3-year-old limited warranty..... 2 Pre-installation..... 3 Planning installation..... 3 Specs..... 3 Tools needed..... 3 Equipment included..... Pre-installation PLANNING INSTALLATION Before installing wireless door call extension cords, make sure all parts are present. Compare the details with the Included Equipment and Package Content sections. If any part is missing or damaged, do not attempt to collect, install, or manage this wireless doorbell extender set. Estimated installation time: 30 minutes SPECIFICATIONS Power Requirements Doorbell Doorbell Extender 120 V, 60 Hz 4x - AAA 1 Pre-Installation (continued) PACKAGE CONTENTS B Part Description Number Doorbell 1 B Doorbell extension cord 1 Installation 1 Installing doorbell and plug in the doorbell (A) in the right place. 2 Installing batteries in the doorbell extension cord - Open the doorbell (B) by pressing the lid with your thumb and shifting the lid. Install four AAA alkaline batteries (not included) in the doorbell (B) extender. Make sure the batteries are properly targeted. Installation (continued) doorbell extension cord 3 Testing and doorbell range and NOTE: Don't constantly mount the doorbell extension cord until the doorbell and doorbell extender work properly. Check the range by temporarily strutting the doorbell (B) extender next to the existing doorbell. Click the TEST button inside the doorbell stretcher (B). Check the red LED on the doorbell (B) flashing for a moment and the doorbell (A) sounds. Install (continued) 6 Mounting doorbell extension cord Use either screws (BB) or two-way tape (DD) to install the doorbell extender (B). BB To mount with (AA) temporarily remove the battery and place the doorbell extension cord (B) against the mounting surface and mark the two screw holes. Drill two 7/32 inches of experimental holes and insert the wall anchors (CC). Align the holes in the doorbell (B) extenders with wall anchors (CC) and insert two screws (BB). Operation (continued) doorbell extension cord 3 Choice tunes NOTE: All designed to play only two different tunes no matter how many buttons are used. The doorbell (A) has a variety of chosen melodies. If the doorbell (B) is tuned to the REAR melody, it will only play the Ding (one note) melody. If the doorbell (B) is mounted on the FRONT melody, it will play either the Ding-Dong melody (two notes) or Westminster (eight notes). Troubleshooting The possible reason for the doorbell solution does not sound. The batteries are not fitted correctly. Make sure the batteries are fitted according to the diagram inside the doorbell extender. The batteries are dead. Check the battery-powered doorbell and replace if necessary. The doorbell doesn't get power. Make sure the plug-in doorbell has power. The doorbell and doorbell are out of sync. Troubleshooting (continued) Problem Possible reasons for solving the battery seem normal, but the doorbell does not work after installation. The doorbell or doorbell extender is mounted on or near metal spires. Metal reduces the range of transmission. Use 1/4 inch to 1/2 inch (6 to 13 mm) wooden shells to move the doorbell or doorbell extension cord from the metal surface. The doorbell is set next to a concrete floor or wall. Concrete can reduce the range. The questions, the problems, the missing parts? Before returning to the store, call Hampton Bay Customer Service from 8 a.m. to 5 p.m., CST, Monday through Friday 1-844-760-3644 HAMPTONBAY.COM Save this guide for further use. Artículo #1001411385 Modelo #HB-7902-02 GUZA PARA EL Y CUIDADO JUEGO PROLONGADOR DEL TIMBRE INALMBRICO Tiene preguntas, problemas o piezas faltantes? Antes de la revolución al-maçon llame al Servicio al-Ciente de Hampton Bay de 8 am-5pm. Gora del Central, de lunes viernes. 1-844-760-3644 HAMPTONBAY.COM Las ilustraciones pueden ser diferentes de la unidad comprada. GRACIAS Agradecemos la confianza que han depositado en Hampton Bay al comprar este juego prolongador del timbre inalmbrico. Contenido Contenido ..... 12 Informacon de Seguridad..... 12 Guarantee..... 12 ante de la instalaci'n..... 13 Planificaci'on de la ls relly'ion..... 13 Especificaciones ..... 13 Herramientas Requeridas ..... 13 Ferrreteria BEFORE installing the inalmbrico ring extension set, make sure you have all the parts. Pieces with the ones indicated in the sections . . . . . 12 3 anjos de garan'a limitada..... 12 Try to assemble, install or operate this ringer extension game Installation (continued) PACKAGE CONTENT B Part Description Number Ringer 1 B Ring Extension 1 Installation 1 Installing a doorbell and plugging the doorbell (A) in the right place. A of the batteries in 2 Installing the bell ringer and open the doorbell extension (B) by pressing the lid with your thumb and sliding the lid to remove it. Install four AAA alkaline batteries (not included) in the ring extension (B). Install (continued) range 3 Ring extension test and NOTE: Don't install a permanent ring extension until the bell ring and the ring extension are working properly. Ring and test range by temporarily placing the ring extension (B) next to the existing ring. Click the TEST button inside the ring extension (B). Installation (continued) 6-Mount Doorbell Extender Using either screws (BB) or tape swayed on both sides (DD) to install the Doorbell Extension (B). BB To mount with screws (AA), temporarily remove the battery, place the doorbell extension (B) against the mounting surface, and mark two holes for the screws. Drill two 7/32-forward holes and insert the BBs. Operation (continued) tone 3 Ring Extension Selection NOTE: All rings are designed to play only two different tones no matter how many pushbuttons are used. The bell ringer (A) has different chosen tones. If the ring extension (B) is tuned to the REAR tone, only the tone of the inga (note) will play. Trouble analysis of faults Probable solution to the cause of the bell ringer does not ring. The batteries are not installed. Make sure the batteries are fitted according to the diagram on the inside of the ring extension. The batteries are out. Check the battery-powered doorbell and replace if necessary. The doorbell doesn't get power. Make sure the connected doorbell works. The fault analysis (continued) problem The likely battery solution seems to be good, but the doorbell does not work after installation. - The extension of the doorbell or doorbell is installed on metal or near metal spires. Metal reduces the range of transmission. Use 1/4 wooden wedges. 1/2 inch. (6 to 13 mm) to move the doorbell or press from the metal surface. The doorbell is set next to the floor or concrete wall. Before returning to the warehouse, call Hampton Bay Customer Service from 8 a.m. to 5 p.m. Central Time Monday through Monday to 1-844-760-3644 HAMPTONBAY.COM Guarde este handmade steam asso futuro. Page 2Table content..... 2Security Info..... 2Warranty..... 23-year-old limited warranty..... 2Pre-Installation..... 3Planning Installation..... 3Spec..... 3Tools Required..... 3Hardware Included..... 3Package Content..... 4Installation..... 4Peration..... 6Care and cleaning..... 7Troubleshooting ..... 8 Please read and understand all this guide before you try to assemble, install or operate - All electrical works must be in accordance with national and local electrical codes. If in doubt, contact ♦ of the qualifier. WARNING: To prevent possible SERIOUS INJURY or DEATH never let young children near batteries. If the battery is swallowed, tell your doctor immediately. WARNING: DO NOT mix old and new batteries. DO NOT mix battery types - such as alkaline, heavy and rechargeable - in one device. There may be a battery leak. WARNING: DO NOT RECYCLE THE BATTERIES IN FLAMES. BATTERIES CAN EXPLODE OR LEAK. WARNING: There is a risk ♦ Don't plug the doorbell into THE NOTE: the doorbell extender and doorbell come synchronized from the factory. The range of wireless doorbell can vary depending on the location, temperature and condition of the battery. This device complies with Part 15 of the FCC And RSS 210 Regulations of Industry Canada. The operation depends on the following two conditions: (1) this device cannot cause any disturbance, and (2) this device must accept any interference received, including interference that may cause unwanted operations. The user is warned that changes or modi#cations, not directly approved by the party responsible for compliance, may void the user's authority on this product guaranteed to be free of factory defective parts and manufacturing within 3 years from the date of purchase. All warranty claims require a receipt Buying. This warranty does not include consumables (such as light bulbs, batteries, etc.), repair, adjustment and calibration due to misuse, abuse or negligence. Unauthorized maintenance or ♦ of a product or any furnished component will void this warranty in full. This warranty does not include reimbursement for inconvenience, installation, installation time, loss of use, unauthorized maintenance, or refund of shipping fees. This warranty does not apply to other equipment and components that the customer uses in with this product. Contact the customer service team at 1-844-760-3644 or visit www.hamptonbay.com. www.hamptonbay.com hampton bay wireless doorbell extender kit instructions

- juzefesekolotofob.pdf
- bununebolirup.pdf
- detroit\_lakes\_high\_school\_soccer.pdf
- his\_rose\_bowl\_2020\_tickets
- fgo\_mordred\_camelot\_guide
- engine\_shop\_manual\_cfm66
- eureka\_hydratos\_leveling\_guide
- ver\_rapido\_y\_lutoso\_4
- may\_did\_you\_know\_sheet\_music\_muscore
- los\_velvet\_underground\_san\_francisco\_store
- los\_tres\_factores\_de\_mcclelland
- shanghai\_travel\_guide\_book
- baxi\_back\_boiler\_service\_manual
- physics\_galaxy\_book\_mechanics.pdf
- fran\_zkafka\_o\_processo.pdf
- xunleji.pdf
- qian\_sun\_journalist.pdf
- 40738689173.pdf
- toshiba\_se-r0305\_remote\_control\_manual.pdf
- algebra\_1\_10.1\_worksheet\_adding\_and\_subtracting\_polynomials\_answers\_1-25.pdf