




I'm not robot



Continue

Pickens county ga assessor's property search

SI. No.Part descriptionPart numberNotesQuantityPurchase 1Pedal box assembly72717-G0includes items 3 - 451 3Accelerator pedal assembly25799-G0includes items 4 - 71 4Accelerator pedal pad kit27844-G0includes items 5-61 5Oval rivet15766-G13/16 x 3/8 LG 6 6Accelerator pedal pad27512-G011 7Accelerator pedal* 8Nylon bushing17838-G13 9Pedal pivot pin74432-G011 10Push nut12064-G69/321 11Clevis pin10386-G35/16 x 1 LG 1 12Teflon washer17255-G15/161 13Cotter pin10387-G33/32 x 3/4 LG1 16Clevis yoke10385-G4Adjustable1 17Lock nut00532-G45/16 - 242 18Accelerator rod72072-G011 19Spring retainer17677-G21 20Compression spring73046-G011 21Accelerator rod bushing17979-G11 22Spring retainer17677-G11 25Micro switch cam72716-G011 26Setscrew00487-G31/4 - 20 x 3/8 LG 1 27Lock nut00550-G45/16 - 241 28Pedal box and cover25853-G031 29Screw01051-G01#8 - 16 x 1/2 LG 4 30Screw00684-G6#8 - 32 x 3/4 LG 4 32Micro switch25861-G011 33Screw01050-G01#4 - 20 x 5/8 LG 2 34Wire harness72201-G04Pedal box1 35Loom flex17313-G1BulkAR 36Wire tie1 7618-G12 38Accelerator cable721713-G021 40Accelerator cable bushing72707-G011 42Cup washer25727-G021 43Lock nut00734-G5#10 - 321 45Accelerator pedal bracket70116-G011 46Bolt00715-G25/16 - 18 x 13/16 LG 4 47Pedal pivot cover70135-G011 49Accelerator cable mounting bracket72701-G011 50Lock nut26830-G01M8 x 1.25 MM2 51Throttle cable mounting bracket72703-G011 52Lock nut26830-G01M8 x 1.25 MM2 55Governor arm72708-G011 58Lock nut26830-G01M8 x 1.25 MM1 59Clamp11845-G31 59Lock nut26830-G01M8 x 1.25 MM1 61Accelerator cable bracket72055-G011 62Wire tie17618-G11 64Governor cover1061decal assembly74457-G01includes items 65, 661 65Governor cover72705-G011 66Decal24880-G01Warning - governor1 67Banded washer00915-G11/42 68Rivet14601-G113/16 x 9/16 LG 2 701Throttle cable72714-G011 71Wire tie17618-G11 Accelerator - Cable and Linkages SI. No.Part descriptionPart numberNotesQuantityPurchase 1Pedal box assembly72062-G03includes items 2 - 471 2Accelerator pedal bracket70116-G011 14Pivot rod72066-G011 14Pivot basket72199-G011 15Lock nut14390-G13/8 - 241 17Micro switch cam72198-G031 18Lock nut00550-G45/16 - 241 19Setscrew00487-G31/4 - 20 x 3/8 LG 1 20Control arm link72074-G011 21Shoulder bolt72225-G01#10 - 24 x 11/16 LG 1 22Lock nut00532-G45/16 - 242 23Spring retainer17677-G11 24Accelerator rod bushing17979-G11 25Compression spring73046-G011 26Spring retainer17677-G21 27Accelerator rod72072-G011 28Clevis yoke10385-G4Adjustable1 29Clevis pin10386-G35/16 x 1 LG 1 30Nylon bos17838-G13 31Teflon washer17255-G15/16 1 32Cotter pin10387-G33/32 x 3/4 LG 1 33Pedale spilpunt 34Push nut12064-G69/321 35Lock nut14390-G10#10 - 241 36Wheel bearing grease12730-G1Not illustrated4R 38Wire harness72201-G02Pedal box1 39Loom flex17313-G1BulkAR 40Wire tie17618-G12 41Accelerator cable727065-G021 42Washer00559-G85/161 43Accelerator pedal assembly25799-G01includes items 44 - 471 44Accelerator pedal pad kit27844-G01includes items 45 - 461 45Oval rivet15766-G13/16 x 3/8 LG 6 46Accelerator pedal pad27512-G011 47Accelerator pedal* 48Bolt00715-G25/16 - 18 x 13/16 LG 4 49Pedal pivot cover70135-G011 51Choke cable72401-G02With nuts1 52Lock washer00568-G49/161 53Nut00545-G49/16 - 181 55Retainer72155-G011 56Choke cable adapter72154-G011 58Jam nut00544-G45/16 - 242 59Carburetor linkage rod25737-G01includes items 60 - 621 60Adjusting rod23722-G1Short1 61Ball joint socket24465-G12 62Nut00526-G4#10 - 322 64Carburetor linkage bellcrank25760-G01includes items 65 - 721 65Carburetor pivot25759-G011 66Bearing23860-G12 67Nylon washer24621-G15/162 68Pivot rod25768-G011 69Push nut12064-G15/161 70Ball joint ball24479-G12 71Lock washer00565-G5#102 72Nut00526-G4#10 - 322 73Pivot bracket72197-G011 74Lock nut14390-G13/8 - 241 75Bolt00414-G81/4 - 20 x 1 LG 2 76Lock nut14390-G41/4 - 202 78Throttle linkage rod assembly72254-G01includes items 79 - 811 79Adjusting rod72609-G01Long1 80Ball joint socket24465-G12 81Nut00526-G4#10 - 322 83Governor pivot bracket assembly25702-G01includes items 84 - 941 84Bellcrank bracket25655-G011 85Lock nut14390-G13/8 - 241 86Governor pivot assembly25763-G01includes items 87 - 941 87Governor pivot25762-G011 88Bearing23860-G12 89Nylon washer24621-G15/162 90Pivot rod25768-G011 91Push nut12064-G15/161 92Ball joint ball24479-G12 93Lock washer00565-G5#102 94Nut00526-G4#10 - 322 96Bolt00276-G65/16 - 24 x 3/4 LG 2 97Lock washer00565-G85/162 99Governor link assembly72573-G03includes items 100 - 1021 100Adjusting rod23722-G11 101Ball joint socket24465-G12 102Nut00526-G4#10 - 322 104Governor bellcrank assembly25690-G01includes items 105 - 1171 105Governor bellcrank25765-G011 106Ball joint ball24479-G11 107Lock nut00734-G5#10 - 321 108Lock nut14390-G41/4 - 201 109Governor bracket assembly22751-G2includes items 110 - 1171 110Governor bracket22752-G11 111Governor rod25274-G11 112Bushing22754-G11 113Cup washer25661-G012 114Compression spring23578-G11 115Bushing22754-G21 116Governor adjuster23859-G11 117Nut00526-G4#10 - 321 118Setscrew00491-G41/4 - 20 x 1/2 LG 2 119Spring25738-G011 120Safety seal25286-G13/81 121Push nut12064-G33/161 123Accelerator cable bracket25653-G011 124Lock washer26826-G018 MM2 125Nut026827-G01M8 X 1.25 MM2 127Accelerator cable bracket72055-G011 128Wire tie17618-G17 Air Filter SI. No.Part descriptionPart numberNotesQuantityPurchase 1Inlet adapter72416-G011 2Gasket72415-G011 3Rivet71055-G013/16 x 3/8 LG 4 4Clamp11391-G21 5Hose72637-G02Convuluted1 7Hose clamp11391-G11 10Air cleaner canister items 160 and 148 - 1561 160Angle canister72598-G011 12Air cleaner cover72599-G011 13Air cleaner latch72604-G012 14Air cleaner dus collector28462-G011 15Air cleaner element28463-G011 17Hose72592-G01Air filter to carburetor1 18Hose clamp11391-G62 19Carburetor gasket26727-G012 20Choke / throttle bracket72739-G011 21Choke bracket26728-G011 22Carburetor adapter72591-G011 23PCV hose72151-G011 24Carburetor mounting spacer23726-G114 25Washer51400-G11/42 26Nut00715-G25/16 - 18 x 13/16 LG 2 177Bolt00438-G85/16 - 18 x 1 LG 2 178Washer00571-G25/162 179Lock nut1098-G65/16 - 182 181Decal35062-G01Workhorse2 182Decal354 183Decal35430-G011200 LX2 184Decal74407-G01Commander2 185Decal74416-G022002 186Decal74416-G012000 SE2 190Cowl ondersteuning arm71463-G011 191Screw00740-G4 # 10 - 32 x 1/2 LG 2 192Washer00559-G5 #10102 193Lock nut00921-G8 # 10 - 322 194Screw16705-G91/4 - 20 x 1 1/4 LG 1 195Retainer neu11776-G11 1/4 - 201 197Fender flare75815-G01Driver side1 198Fender flare75815-G02Passenger side1 199Rivet71045-G015/32 x 3/4 LG 6 200Washer00559-G4#86 203Spacer23726-G21/42 206Cowl renfoit service kit73464-G01includes items 72 - 74, 86 and 871 Brakes SI. No.Part descriptionPart numberNotesQuantityPurchase 1Brake pedal assembly70612-G01without brake lights, includes items 2 - 101 2Torsion spring70681-G012 3Pivot pin70682-G011 4Pushnut01071-G0115 5Brake pedal* 1 6Park brake pedal70611-G011 7Brake/park brake pedal pad kit70274-G01includes items 8-101 8Service brake pad* 1 9Park brake pedal pad* 1 10oval rivet15766-G13/16 x 3/8 LG 9 12Shoulder bolt70582-G013/8 - 16 x 1 LG 1 13Flanged bushing70581-G011 14Torsion spring70676-G011 15Washer00643-G13/81 16Lock nut11098-G53/8 - 161 18Compensator assembly70272-G04includes items 19 - 201 19Spherical nut00963-G015/16 - 241 20Lock nut11098-G95/16 - 181 22Equalizer and brake cable assembly70969-G05includes items 23 - 261 23Bracket compensator bumper28083-G012 25Brake cable*Driver side1 26Brake cable*Passenger side1 28Retaining ring12305-G14 30Clevis pin10386-G35/16 x 1 LG 3 31Cotter pin10387-G33/32 x 3/4 LG 3 32Clevis pin14443-G25/16 x 3/4 LG 2 34Kick-opp link70601-G011 35Nylon bushing17838-G12 36Teflon washer20835-G1382 37Washer00559-G85/16 - 162 38Cotter pin10387-G33/32 x 3/4 LG 2 39Kick-off cam727098-G011 40Flanged bearing10097-G62 41Kick-off cam70587-G011 42Setscrew71215-G011/4 - 20 x 1/2 LG 2 43Adjustable bumper70113-G011 46Lock nut11027-G15/16 - 181 48Catch bracket70080-G011 49Bolt00414-G61/4 - 20 x 3/4 LG 2 50Lock nut00891-G21/4 - 202 53Brake pedal assembly70690-G01With brake lights, includes items 54 - 801 54Brake pedal* 1 55Park brake pedal70611-G011 56Brake / park brake pedal pad kit70274-G01includes items 57 - 591 57Service brake pad* 1 59Oval rivet15766-G13/16 x 3/8 LG 9 61Brake pedal plate70258-G021 62Pivot pin70682-G011 63Torsion spring70681-G012 64Pushnut01071-G0115 65Screw00737-G8#10 - 24x 1 LG 4 66Rubber nut00739-G1#10 - 242 67Brake pedal standoff22362-G32 68Conical spring27137-G012 69Lock nut11098-G7#10 - 242 70Micro switch10606-G81 71Screw00957-G1#6 - 32 x 1 1/4 LG 2 72Washer00559-G5#102 73Washer00565-G3#64 74Lock washer00565-G3#62 75Nut00525-G5#6 - 322 76Screw and lock washer13514-G1#62 78Faston tab14628-G12 79Wire harness24605-G1Brake light1 80Wire tie17618-G13 82Brake assembly70793-G01Driver side , sluit items 84 - 921 83 Rem vergadering70793-G02Passenger kant, sluit items 94, 951 94Adjuster * 1 washer* 96Bolt17083-G25/16 - 24 x 1 LG 8 97Lock nut15126-G15/16 - 248 98Inner brake drum washer21809-G11 5/16 OD X 1 ID X 1/322 100Brake drum assembly21807-G1includes items 101 - 1022 101Brake drum* 1 102Lug bolt19862-G11/2 - 204 105Outer brake drum washer21830-G12 106Slotted nut00518-G83/4 - 162 107Cotter pin10387-G11/8 x 1 1/2 LG 2 108Spindle cap74175-G012 110Brake cable bracket72036-G02passenger side1 111Brake cable bracket72237-G02Driver side1 Cab (Early Production) SI. No.Part descriptionPart numberNotesQuantityPurchase 1Steel cab*Without doors 1 2Roof panel74228-G0*A1 3Rear panel74228-G0*B1 4Windshield panel74228-G0*C1 5Front corner panel74228-G0*DPassenger side1 6Front corner panel74228-G0*EPassenger side1 7Receiver74228-G0*FDriver side1 8Receiver74228-G0*GPassenger side1 9Lower mounting bracket74228-G0*HDriver side1 10Lower mounting bracket74228-G0*IReceiver side1 11Adjustable bumper70113-G012 12Front panel cover seal gasket1P004A85 LG 1 13Roof trim1P004D501 15Front windshield mounting gasket6E03.1 16Bolt6E03A3/8 - 16 x 7/8 LG 44 17Lock nut6E03B3/8 - 1644 18Washer6E03C3/844 19Nylon washer6E03D3/826 20Front panel window6E03E1 21Front corner panel mounting gasket6E03H2 22Rear panel window mounting gasket6E03I1 23Allen button head bolt6E03S4 25Bolt6E03U1/4 - 20 x 1 1/2 LG 4 26Nylon spacer6E03V1/44 29Front corner panel window6E05APassenger side1 30Front corner panel window6E05BDriver side1 31Rear panel window6E05C1 33Windshield wiper kit74244-G01includes items 34 - 421 34Wiper motor9PWW85includes items 35 - 391 35Spacer* 1 36Shaft cover*Seal1 37Nut* 1 38Bolt* 1 39Washer* 1 40Wiper arm9PWA1 41Windshield wiper blade9PWB1 42Electrical hardware kit9E003.Not illustrated 44Steel door kit74301-G0includes items 45 - 651 45Steel door74301-G0*ADriver side, includes items 47 - 521 46Steel door74301-G0*BDriver side, includes items 49 - 541 47Sliding door window assembly6E05DDriver side1 48Inside door latch9DHSLLDriver side1 49Lower door window mounting gasket6E03P1 50Lower door window6E05F1 51Outside door handle9DHOS1Key locking2 52Lower door seal gasket1P004B43 LG 1 53Sliding door window assembly6E05EPassenger side1 54Inside door latch9DHSLRPassenger side1 55Door seal gasket1P004C123 LG2 56Replacement door hinge kit9P001ANot illustrated4R 58Vinyl door kit74242-G01includes items 59 - 661 59Vinyl door9DVK-LDriver side , sluit items 61, 63-661 60Vinyl deur9DVK-RPassenger kant, sluit items 62 - 661 61Inside deur grendel9DHSLLDriver side1 62Inside deur grendel9DHSLRPassenger side1 63Door check9DCKNot geïllustreer1 64Door striker9DSTK1Not geïllustreer1 65Door gryp handvatsel9DGH11 66Outside deur handvatsel9DHS1Key sluit1 67Verplasing deur skarnasie9PSSHLDriver kant, nie geïllustreer1 68Replacement deur skarnasie9PSSHRPassenger kant, nie geïllustreer1 70Strobe lig kit74245-G01includes items 71 - 751 71Strobe lens9PSLRL1 72Elektrise hardware Illustrated1 73Toggle switch9E002.1 74Replacement bulb9PSLRBNot illustrated1 75Bracket9PB0011 77Work light kit74247-G01includes items 78 - 811 78Work light9LW1Includes hardware2 79Electrical hardware kit9E001.Not illustrated1 80Toggle switch9E002.1 81Bracket9PB0011 83Defroster / cooling fan kit74248-G01includes items 84 - 861 84Fan9PDF1 85Electrical hardware kit9E001.Not illustrated1 86Hardware kit9PFH1 88Switch panel kit74250-G01includes items 89 - 1031 89Switch panel9PSF1-0011 90Mounting bracket and hardware9PSF1-0021 91Adhesive labels9PSF1-0031 923 AMP fuse9PSF1-004Not illustrated2 935 AMP fuse9PSF1-005Not illustrated3 947.5 AMP fuse9PSF1-006Not illustrated2 95AMP fuse9PSF1-007Not illustrated3 964 X 10 FT LG (Not illustrated)1 964 vaf base tie9PSF1-008Not illustrated6 97Wire tie9PSF1-009Not illustrated14 98Bolt9PSF1-0101/4 - 20 x 7/8 LG 2 99Washer9PSF1-0111/4 100Nylon washer9PSF1-0121/42 101Lock nut9PSF1-0131/4 - 202 10210 GA wire9PSF1-014Red 8, not illustrated1 10310 GA wire9PSF1-015Black 8, not illustrated1 105Steel cab*Without doors, , includes items 1061 106Windshield panel74227-G0*C1 107Front corner panel74227-G0*DPassenger side1 108Front corner panel74227-G0*EDriver side1 111Bed spacer6E03T2 Cab (Late Production) SI. No.Part descriptionPart numberNotesQuantityPurchase 1Carburetor assembly72558-G01For fuji engine pin EH35CP65032, includes items 3,5-7, 9-201 2Carburetor assembly72558-G05For fuji engine pin EH35CP65033, includes items 4-7, 8-201 3Main jet26646-G09#921 4Main jet26646-G07#901 5Carburetor

