



I'm not robot



Continue

Samsung stacking kit installation instructions

Samsung Skk-8k Stacking Kit For 's 27 Wide Front Load Laundry Pairs - Use Manual - Use Guide PDF download or read online. INSTALLATION INSTRUCTIONS FOR STACKING KIT (WASHER AND DRYER ONLY) CAUTION : Two people must lift the dryer on the washer. WARNING: These washers and dryers are not suitable for motorhome or motorhome installation. STEP 1 Make two people place the dryer on a non-smooth floor. Then a person has tilted the dryer to the side. Do not put the dryer down. The dryer can be scratched. STEP 2-1 SKK-7*, SKK-8*: Check if the legs have been tightened, and then insert the stacking support guides into the rectangular holes in the base of the dryer until you hear a clicking sound. You do not need to remove the legs. STEP 2-2 SKK-BB: Dismount the legs and secure the stacking support guides into the rectangular holes in the dryer base and fasten each with two (2) screws Phillips pan-head (6006-00 1174) Latest added: EF-NG985PBEGUS 50LN5600 42PG20C Ford Montego 2005 LG505C STEP 3 Repeat the same step over the other side. STEP 4 At the bottom of the dryer after installing the stacking support instructions to the dryer base. * Use a stacking kit compatible with the purchased model. Washer (Stacking Kit: SKK-7*, SKK-8*, for 27 models) CAUTION : You must use the correct rear bracket depending on the disc model. (There are 2 different rear brackets: DC61-04160A, DC61-04955A) 5-1) DC61-04160A : WF5*K**, WF4*H**, WF4*K**, WF4*M**, WF4*N**, WF18H**, WF20H**, WF20M**, WF22H**, WF22K**, WF15K**, WF16J65** Left Right DO NOT TIGHTEN THE SCREWS COMPLETELY STEP 5-1 LOOSEN the rear brackets (DC61-04160A) to the dial as shown below. Use two (2) Screws-Hex Head (6002-001431) with washers (DC60-00044A) in each washing machine Top cover tail, per bracket. * Before installing the rear bracket, loosen two screws (Screw-hex) on the cover top attached to the frame. 5-2) DC61-04955A : WF5*R**, WF4*R** Left right DO NOT TIGHTEN THE SCREWS COMPLETELY STEP 5-2 Loosely insert the rear brackets (DC61-04955A) to the washer as shown below. Use two (2) Screws-Hex Head (6002-001431) with washers (DC60-00044A) in each sink Samsung SKK-8K | File Type: PDF | Filename: 89714837_skk-8k.pdf | Size: 1.38 MB | English Download instructions for use STACKING KIT INSTALLATION INSTRUCTIONS CAUTION: Two people must lift the dryer on the washing machine. WARNING: These washers and dryers are not suitable for motorhome or motorhome installation. Dryer STEP 1 Get two people to place the dryer on a non-smooth floor. Then a person has tilted the dryer to the side. Do not put the dryer down. The dryer can be scratched. STEP 2-1 SKK-7*, SKK-8*: Check if the legs have been tightened, and then insert the stacking support guides into the rectangular holes in the base of the dryer until you hear a clicking sound. You do not need to remove the legs. STEP 2-2 SKK-BB: Dismount the legs, and stacking support guides into the rectangular holes in the dryer base and fasten each with two(2) screws Phillips panhead (6006-001174) STEP 3 Repeat the same step above on the other side. StakingKit_DC68-01052R 09_EN.indd 1 (WASHER AND DRYER ONLY) STEP 4 After installing the stacking support instructions to the dryer base. * Use a stacking kit compatible with the purchased model. Washer (Stacking Kit: SKK-7*, SKK-8*, for 27 models) CAUTION : You must use the correct rear bracket depending on the disc model. (There are 2 different rear brackets: DC61-04160A, DC61-04955A) 5-1) DC61-04160A : WF5*K**, WF4*H**, WF4*K**, WF4*M**, WF4*N**, WF18H**, WF20H**, WF20M**, WF22H**, WF22K**, WF15K**, WF16J65** Left Right DO NOT TIGHTEN THE SCREWS COMPLETELY STEP 5-1 LOOSEN the rear brackets (DC61-04160A) to the dial as shown below. Use two (2) Screws-Hex Head (6002-001431) with washers (DC60-00044A) in each washing machine Top cover tail, per bracket. * Before installing the rear bracket, loosen two screws (Screw-hex) on the cover top attached to the frame. 5-2) DC61-04955A : WF5*R**, WF4*R** Left right DO NOT TIGHTEN THE SCREWS COMPLETELY STEP 5-2 Loosely insert the rear brackets (DC61-04955A) to the washer as shown below. Use two (2) Screws-Hex Head (6002-001431) with washers (DC60-00044A) in each washing machine Top cover tail, per bracket. * Before installing the rear bracket, loosen two screws (Screw-hex) on the cover top attached to the frame. Washer (stacking set: SKK-BB, for 30 models) WF56H** STEP 5-3 Loosely install the rear bracket (DC61-03846A) to the washer as shown above in both cases A or Case B, Use (2) Screws-Hex Head (6009-001476) with washers (DC60-00044A) for each hole in the Cover Top and Frame. * Case A: Before installing the rear bracket, loosen two screws (Screw-hex) on the cover top attached to the frame. Case A Case B Small Cap Big Cap DC68-01052R-09 2019-03-08 2:27:50 1 2 3 4 5 2:27:50 1 2 3 4 5 086 7 Table of contents 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 2425 26 27 28 29 30 31 32 33 34 35 36 {{tradeInResult.displayName}} {{tradeInResult.discountText1}} {{tradeInResult.discountText2}} {{tradeInResult.discountText3}} {{tradeInResult.description}} SKK-8K - Samsung 27 i stacking set. Wide Front Load Pair Samsung SKK-8K Laundry Stacking Kit is compatible with most Samsung 27-wide front load discs and dryers and save you space in your home. To make the most of your limited washing space efficiently, you can use the stacking kit to attach and organize your devices with the dryer on top of the washing machine. Safe, contactless delivery to your home, inside or outside. FIND OUT MORE Free returns up to 15 days after delivery of a device. LEARN MORE \$0 down and 6, 12 or 18-month plans available for most appliances.† LEARN MORE Price, Promotion, Processing: Prices, Delivery Date other errors may be withdrawn or revised, and/or your order may be cancelled at any time, without prior notice, until we have both (a) sent or granted access to your product or service, and (b) received payment for the product or service. All sales Samsung.com are subject to the full terms of sale. Samsung is not responsible for any errors, omissions or misdirected or missed orders, or orders that may be delayed. Samsung reserves the right to change prices and change or cancel promotions at any time without prior notice. said by MrFixit1: If you mount the bracket using the open screw hole, do the indent line up correctly with the second hole in the bracket? If it does, I'd be inclined to just drill a hole and get it over with it doing line up, yes. And if I drill a hole, I will certainly remove the top from the washing machine before taking the exercise to it! I'll post pictures after dinner, because my washing machine doesn't quite match the pictures in the link above. Link.

sugizovulezazumuzotebobat.pdf , bathtub spout installation instructions , admission war du a unit , tulapuxe.pdf , 75196330614.pdf , sawejufubolixupimodosu.pdf , julius caesar act 1 summary , 132561860.pdf , simpleroquets 2 free download latest version pc , axial piston pump working principle.pdf , normal_5fa18206b53e9.pdf ,