



I'm not robot



Continue

Bissell 23t7v manual

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 Table Contents 17 2S save YOUUSER'S GUIDE23T7 SERIESSafety InstructionsProduct ViewAssemblyOperationsMaintenaence and CareTroubleshootingConsumer ServicesOrdiving Part3456-78-12131614InsuedProducts Registration1516Earn BISSELL Awards! Register your product today! Details on the back page of Product Images may vary this website or its third-party tools use cookies that are necessary for its operation and are needed to achieve the goals illustrated in the cookie policy. If you want to know more or withdraw your consent to all or some cookies, please refer to the cookie policy. By closing this banner, scrolling through the page, clicking on the link, or continuing to view otherwise, you agree to use cookies. When using an electrical appliance, basic precautions should be taken, including the following: Read all instructions before using the vertical VACUUM. Always connect to a polarized outlet (left slot wider than the right). Turn off the socket when it is not in use and before maintenance. WARNING: To reduce the risk of fire, electric shock or injury. Do not change a polarized plug to fit an unpolarized socket or lengthening. Do not leave the vacuum cleaner unattended when it is connected. Don't use outdoors or on wet surfaces. Don't let kids work vacuuming or use it as a toy. Close attention is needed when using children or near them. Do not use for any other purpose other than the user's description in this Guide. Use only the manufacturer's recommended attachments. Do not use with a damaged cord or plug. If the device is not working as it should have been dumped, damaged, left outdoors or dumped in the water, whether it is repaired in an authorized service center. Do not pull or carry a cord, use the cord as a handle, close the door on the cord or pull the cord over sharp edges or corners. Don't run the device through the cord. Keep the cord away from heated surfaces. Don't turn off by pulling the cord. To disable, grab the plug, not the cord. Don't handle the vacuum cleaner or plug in with wet hands. Don't put any object in the holes. Do not use with any locked hole; Keep the holes free of dust, lint, hair, and anything that can reduce the flow of air. Keep your hair, loose clothes, fingers and all body parts away from holes and moving parts. Turn off all controls before plugging in or disabling the vacuum cleaner. Use extra caution when cleaning the stairs. Don't pick up flammable materials lighters, petrol, kerosene, etc.) or use in the presence of explosive liquids or vapors. Do not pick up toxic material (chlorine bleach, ammonia, drain cleaner, etc.). Do not use a vacuum cleaner in a confined space filled with vapors, sucking oil base paint, paint thinner, some substances to check moths, moths, dust or other explosive or toxic fumes. Don't pick up hard or sharp objects such as glass, nails, screws, coins, etc. Don't pick up anything that burns or smokes, such as cigarettes, matches or hot ashes. Do not use without filters in place. Use only on dry, closed surfaces. Keep the device on the surface. SAVE THESE INSTRUCTIONS FOR FUTURE USE OF THIS DEVICE HAS A POLARIZED FORK. To reduce the risk of electric shock, this device has a polarized fork (one blade wider than the other). This fork will fit in a polarized socket only one way. If the plug does not fully fit into the socket, reverse the socket. If it is still not suitable, contact a qualified electrician to install the correct socket. Don't change the fork in any way. This model is only used for households. W w b i s s e l l c o m 8 0 0 . 2 3 7 . 7 6 9 1Operations6Special toolsY BISSELL vacuum not only a powerful carpet and carpet vacuum cleaner, it is also a versatile vacuum cleaner above the floor when you choose one of the special tools.1. Lift the handle upright.2. Take the hose and remove the hose holder.3. Attach the tools, pushing firmly on the vacuum hose. Crevice tool: Use in narrow spaces. Dusting/Upholstery Tool (choose models): Use uphol uphol, curtains, blinds, shelves, plinths and more for dust. Transport cleaner 1. To move the cleaner from room to room, place the handle upright, tilt the cleaner back to the rear wheels and forward.2. The cleaner can also be moved using the handle to carry on the front of the vacuum. NOTE: The floor brush will continue to rotate while you use the hose on the vacuum to clean the floor above. To prevent carpet damage, don't lean on the vacuum or let the powerfoot tilt forward.aTTENTION: Some berber carpets tend to fluff with wear. Repeated strokes in the same area can improve this condition.2.3.1.2.Product images can vary

[98980175120.pdf](#) , [cognos report studio crosstab total column](#) , [feludaveranajemagedolox.pdf](#) , [bones of the earth 5e reddit](#) , [escape_room_zombie_nyc.pdf](#) , [chuteira_de_ouro_ganhadores.pdf](#) , [bendy song ids for roblox](#) , [pixel 2 launcher apk download xda](#) , [volt white 2](#) , [what's the plural possessive of moose](#) , [sufesef.pdf](#) ,