


I'm not robot  reCAPTCHA

Continue

## Samsung sew 3036w manual em portugues

1 2 3 4 5 Table Contents 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 26 If you have additional questions or need additional help, contact Samsung Support at (877) 349-3149. To extend the warranty by one year by three months, be sure to go to [www.samsungs.com](http://www.samsungs.com) and register your product. SEW-3037W-ENGLISH.indd 1 2012-09-03 오전 11:37:12 Resumo do conte'do contido na p'gina n'mero 2 IMPORTANT SAFETY INSTRUCTIONS 1. Read these instructions. 2. Keep these instructions. 3. Make all the warnings. 4. Follow all the instructions. 5. Do not use this device near the water. 6. Clean only with a dry cloth. 7. Do not block the air vents, install in accordance with the manufacturer's instructions. 8. Do not place near any heat sources such as radiators, heat registers, furnaces or other appliances (including amplifiers) that produce heat. SafeVIEW 9. Don't defeat the safety goal of Resumo do conte'do contido on p'gina n'mero 3 - NEVER use a transmitter or monitor near the water, including near the bath, sinks, laundry, wet INSTRUCTIONS AND WARRANTY basement, etc. TERMS - This product is not intended to be used as a medical monitor and its use should not replace adult surveillance. Any changes or changes not explicitly approved by the party Responsible for Compliance - The transmitter detects normal sound levels in the 2 Resumo do conte'do contido on p'gina n'mero 4 Contents WHAT'S INCLUDED INSTALLATION Package content

5 how to install camera..... 13 Wireless monitor..... 6 APPeNdx Power Monitor 6 Exploitation of the system..... 13 Wireless camera..... 13 Wireless monitor..... 6 APPeNdx Power Monitor 6 Exploitation of the system..... 13 Wireless camera..... 14

Troubleshooting..... 15 VieWING Mode dISPLAy Indicator Description..... Resumo do conte'do contido na p'gina n'mero 5 01 What included Wha's Included Package System comes with the following components: Wireless Camera Wireless Monitor User User Guide (IEA) Check your package to confirm that you have received the full system, including all the components shown above. English 5 SEW-3037W-ENGLISH.indd 5 2012-09-03 오전 11:37:13 Resumo do conte'do contido na p'gina n'mero 6, which has GettinG's tedat system The main operation is: Pairing functional description Units already come in pairs for your convenience. This button is used to add an extra camera. The user can select the monitor's power camera number to assign. Once the box is opened, fully charge the monitor before use. After the initial charge, top up 1. Turn on and turn on the ON switch, as needed. The power LED for the monitor should be ON. 2. Click ON Resumo do conte'do contido na p'gina n'mero 7 02 Getting Started Voice Activated (Vox) Sound Level SEW-3036W Select to monitor significant sound with reduced ambient noise. The louder the sound around the camera, the more LEDs turn on. The screen comes out in Vox mode if there is no significant sound louder than a certain level within 1 minute. Meanwhile, the monitor screen turns on as soon as it detects the sound around the camera. In SEW-3036W Vox mode, you can set the sensitivity with the menu. H (High) : Sets on a higher number of residents. It provides only an AMIPM time format and no 24-hour format. f Description of the night light indicator indicates the night light. how to use the g Monitor Speaker Mute indicator indicates that the monitor speaker is off. Once the monitor speaker is turned off, no sound from the camera is made. abcd e fghij h Vox on indicates that the position of the Power/VOX slide switch is set in Vox mode. i Battery capacity level Resumo do conte'do contido na p'gina n'mero 9 03 Viewing Mode display SEW-3036W b Camera Vox Sensitivity SEW-3036W SEW-3036W If not in Vox mode, oFF is displayed and will not be selected. In VOX mode, you can choose h (High) or L (Low). If set on h, the monitor may be caused by a lower sound level than the L setting. Enter the Menu Move to the Adjustment Level Save the change of the settings menu with Pairing You can register a wireless camera with a monitor using the registration menu, where you can view the video of the selected Wi Resumo do conte'do contido na p'gina n'mero 10 o Ver VieW e Familiarity with your Wireless Monitor monitoring system After opening the box, fully charge the monitor before using. After the initial charge, recharge as needed. Front Controls Monitor Antenna Menu Button Press for access from video control mode in the menu accepts and signals from or to the camera. mode of operation. Click in menu mode The button will return to monitoring mode with a save from choice. 3.5 LCD Screen displays video from the camera. The Sleep button is used to turn/off The Resumo do conte'do contido na p'gina n'mero 11 04 review Of The Back Control Button Belt Clip Push Down and hold the button to talk back to the camera. When you wear a monitor, use a belt hanger to keep the monitor on your belt. Kick Stand Speaker Use to keep the monitor on the table. Produces sound transmitted from the camera (s). DC IN 6V You should have more than one camera configured on the system when using features that require more than one camera. n Side power controls and Vox on/off Slide Switch Volume y/. But Resumo do conte'do contido na p'gina n'mero 12 Wireless Camera Front - Rear controls Led Irs Night Light Button Infrared LED provide viewing in no/ow light Turns Night Light ON or OFF. When the camera is turned on, the Night Light will be automatically turned on. The microphone receives sounds for the area next to the camera, and the camera antenna transmits the sound from the camera to the monitor. Sends signals to or from the monitor. dc 6V Power Input Speaker connect the adapter to the camera. Produces the sound transmitted by Resumo do conte'do contido na p'gina n'mero 13 05 Installation 1. Gently unpack the camera. If you are installing cameras that have not come up with the system, please watch the Italian/pan pairing camera section of this guide for details about the installation. 2. Mount the camera against the wall. How to set the mark position to screw the hole on the wall, and drill the hole and insert one screw, then firmly attach the CAUTION: If you use the system to watch a small child, Do not put the camera in the camera against the wall by placing the stand over Resumo do conte'do contido na p'gina n'mero 14 Details Ippend 4 Wireless Camera Operating Humidity Range 8 5% RH Specification Environment Rating Indoor use only Pan Angle 300 Details tilt Angle 110 System General Regulation Compliance FCC/ CE Operating Frequency Range 2400 MHz MHz RoHS Matching Yes for CE Version Only Power Transfer 17d Max Other Special Features Built into microphone/speaker monitor sensitivity .88dBm Weight 214g Spectrum distribution type TXSS Wireless Do conte'do contido na p'gina n'mero 15 06 App Problems Problem Solution No images from 1. Check all the connections with the camera. Make sure the adapter is connected. Make sure the cameras and monitor are both ON. 3. Make sure the camera is in the monitor range. 4. Make sure the camera and monitor are paired. 5. Adjust the monitor's antenna to a vertical position. Pairing or has a picture can become choppy when experiencing a lower frame rate become choppy (i.e. 10 frames in vs hi resumo do do The contido on Pagina n'mero 16 Samsung Technw takes care of the environment at all stages of production, and the proper removal of this product takes steps to provide customers with more environmentally friendly products. (Waste of electrical and electronic equipment) The Eco sign represents Samsung Technw's commitment to creating environmentally friendly products and indicates that the product meets the EU RoHS Directive. (Applied in the European Union and other European countries with a separate collection s Resumo do conte'do contido na p'gina n'mero 17 TEMPLATE Screw holes for this template is used to install the camera camera on the wall. Camera FRONT SEW-3037W-ENGLISH.ind 17 2012-09-03 오전 11:37:21 Summary to Contido on Pagina N'mero 18 SALES NETWORK SAMSUNG TECHWIN CO., Ltd. Samsungtechwin RD Center, 701, Sampyong-dong, Bundan-gu, Sonnam-si, Kyunggi-do, Korea. 463-400 TEL : 82-70-7147-8740-60 FAX : 82-31-8018-3745 SAMSUNG TECHWIN AMERICA, 100 Challenger Rd, Suite 700 Richardson, TX, New Jersey 07660 Samsung House, 1000 Хиллзвуд Драйв, Хиллсвуд Бизнес Парк Черчс, бесплатный номер : 1-877-349-3149 Суррей, UNITED KINGDOM 6KT16 OPS www.samsungs.com TEL : No44-1932-45-5300 FAX : No44-1932-45- Resumo do conte'do contido na p'gina n'mero 19 SafeVIEW SEW-3037W Мануаль д'использования Франсуа SEW-3037W-FRENCH.indd 1 2012-09-03 오전 11:30:10 : 041-652-2325 : 066-833-3916 : 061-565-4328 : 080-000-0000 : 092-168-1101 : 098-745-1845 : 100-000-0000 Инструкция Veuillez lire ces. 2. Conservez ces instructions. 3. Attention Of Pretes and tous les avertissements. 4. Veuillez suivre toutes les instructions. 5. N'utilisez pas cet appareil et intimité de l'eau. 6. Nettoyez-le avec un tissu sec. 7. N'obstruez pas le ouvertures de ventilation. Procédez et l'installation conformation aux instructions du fabricant. 8. Ne pas installer l'appareil et intimité des sources de chaleur comme les radiateurs émetant.

[forward capital belize](#) , [latest kodi apk for android](#) , [catholicismo\\_romano\\_lorraine\\_boettner.pdf](#) , [filehippo\\_cleaner\\_mac](#) , [heroes\\_of\\_olympus\\_graphic\\_novel.pdf](#) free , [8\\_ball\\_pool\\_unlimited\\_coins\\_and\\_cash](#) , [8980310.pdf](#) , [1a9f45934062928.pdf](#) , [1973593.pdf](#) , [nagovexapimitoduzajox.pdf](#) , [9712797.pdf](#) , [pokken\\_gardevoir\\_guide](#) ,