

# PRODUCT DATA

## EGGSHELL ENAMEL



### Type

An Alkyd Resin-based Topcoat with a Medium Sheen for Interior Use Only.

### Appearance

Dries to a pleasant medium sheen.

### Properties and Uses

Titanium Eggshell Enamel is suitable for internal use only on suitably primed and prepared surfaces.

### Surface Preparation

Essential for good paint performance is a sound substrate that has been properly cleaned and prepared. On existing painted surfaces it is recommended that a small section of paint be removed to establish the condition of the original paint and the substrate. Where there is doubt, the paint must be removed to a sound base. All surfaces must be dry, free from loose and flaky material, grease and fungus prior to applying the new paint system.

### Application Instructions

These instructions are issued as an aid in determining correct surface preparation, mixing and application procedure and should be closely followed to obtain maximum service from the material.

#### 1. New Unpainted Wood Surfaces

- (a) Prime with Titanium White Wood Primer.
- (b) Leave for 24 hours and apply one coat Titanium Universal Undercoat.
- (c) Allow to dry for 16 hours. Sand lightly, then apply two coats of Titanium Eggshell Enamel, allowing a minimum of 16 hours between coats.

#### 2. Old Painted Wood Surfaces

- (a) Remove all loose and flaky paint and sand lightly.
- (b) Spot-prime bare areas with Titanium White Wood Primer.
- (c) Allow to dry for minimum 24 hours, and then apply one coat Titanium Universal Undercoat to entire area.
- (d) Allow to dry for 16 hours, sand lightly then apply 2 coats Titanium Eggshell Enamel, allowing a minimum of 16 hours between coats.

#### 3. New Unpainted Metal Surfaces

- (a) Remove any rust, grease or dirt and prime with Titanium Waterbased Metal Primer.
- (b) Allow to dry for a minimum of 6 hours, and then apply one coat Titanium Universal Undercoat.
- (c) Allow to dry for a minimum of 16 hours, sand lightly then apply 2 coats of Titanium Eggshell Enamel, allowing a minimum of 16 hours between coats.

#### 4. Old Painted Metal Surfaces

- (a) Remove all loose and flaky paint and sand lightly.
- (b) Spot-prime bare areas with Titanium Waterbased Metal Primer.
- (c) Allow to dry for a minimum of 6 hours and then apply one coat of Titanium Universal Undercoat.
- (d) Allow to dry for a minimum of 16 hours, the apply 2 coats of Titanium Eggshell Enamel, allowing a minimum of 16 hours between coats.

<b><u>Application Method:</u></b>	Brush, mohair roller or airless spray.
<b><u>Spreading Rate:</u></b>	± 8m <sup>2</sup> per litre per coat on smooth surfaces.
<b><u>Drying Time:</u></b>	Surface dry 4 hours and hard dry 16 hours at 25°C.
<b><u>Cleaning of Utensils:</u></b>	Mineral Turpentine.
<b><u>Packaging Sizes:</u></b>	5 L and 1 L
<b><u>Colour Range:</u></b>	White and a variety of standard colours or any other special tint.