EuroDesign

Wood Engineering

INSTRUCTIONS HOW TO REPAIR CUTS IN A TEAK COMPOSITE DECKING



There are two methods:

A) Small holes:

For small holes, the best way is to use composite dust and super glue:

- 2. First clean the area so the glue stick to the surface
- 3. Fill the hole with composite dust
- 4. Apply a drop of super glue
- 5. Press down the dust/glue
- 6. Use a cutter to cut off excess glue dust
- 7. Sand off the area to make it smooth
- 8. Use a tool with a 40 grit sandpaper to re-brush the area





EuroDesign

Wood Engineering

B) Bigger holes:

For bigger holes cut a piece of composite and glue on with super glue:

- 1. Cut a piece of composite in a similar shape os the hole
- 2. Clean the surface so the glue stick to the surface
- 3. Apply a drop of super glue in the hole
- 4. Press down the composite piece
- 5. Use a cutter to cut off excess composite
- 6. Sand off the area to make it smooth
- 7. Use a tool with a 40 grit sandpaper to re-brush the area









