

JM400

Multi-Purpose Adhesive

JM400 Multipurpose Adhesive is a superior performing high solids, water based floorcovering adhesive offering fast wet grab and strong final bond. The adhesive is designed to suit a wide range of carpets. This includes carpets with hard to bond synthetic backings, such as latex/unitary or Action-Bac as well as Axminsters and jute hessian backed.

The adhesive is easy to spread, is suitable for use over normal underfloor heating installations, and will withstand normal wet cleaning techniques.

TECHNICAL SPECIFICATIONS

PRODUCT CODE

JM400

PRODUCT NAME

Multi Purpose Adhesive

CONTAINER SIZE

5kg & 15kg plastic buckets

TYPE

Rubber/Resin Emulsion

COLOUR

Off White

VISCOSITY

70,000 - 90,000cps at 20°C

COVERAGE

Approximately 2-3m² per kg depending on trowel used and absorbeny of sub floor

OPEN TIME

Between 20-40 mins, depending on temperature, humidity, sub floor porosity & trowel used

STORAGE

Store between temperatures of 5°C & 30°C

SHELF LIFE

12 months in unopened containers, stored in recommended conditions

CLEANING

Tools should be cleaned with water whilst the adhesive is wet. Use hot water or Morleys Solvent Cleaner should the adhesive dry. Do not use on the skin

Health and Safety Sheets available on request



JM400

Multi-Purpose Adhesive

USES

JM400 can be used to install the following: Carpets: Jute secondary backed, Axminster, Wilton, synthetic secondary backed, needlepunch/fibrebonded, latex/unitary backed, Action-Bac, latex foam, gel back, felt back and bitumen/non woven backed. For carpets recommended for "double stick" systems the JM400 is an ideal permanent bond adhesive. Do NOT use for: Urethane backed carpets.

SUBFLOORS/WALLS

Suitable subfloors include concrete, sand/cement screed, smoothing underlayment, plyboard, flooring grade chipboard, hardboard, wood and existing well bonded resilient flooring. **There are certain grades of floor/wall board that have been treated with paraffin wax to provide a waterproof quality. There are also other types floor/wall boards in use that have been treated, e.g. moisture proofing, preservatives and fire retardants. These types of boards are not suitable with this adhesive. Please always check the floor/wall board in use at each installation. Please contact the office for technical information. With existing well bonded resilient flooring care must be taken to ensure the subfloor under the resilient flooring is sound and the surface of the resilient flooring is thoroughly cleaned of any polish etc. If this cannot be done, the existing resilient flooring must be removed and the subfloor made good before proceeding.

PREPARATION

All parts of the installation should comply with the latest edition of the following British Standard Code of Practice: BS5325 The Installation of Textile Floorcoverings or BS8203 The Installation of Resilient Floorcoverings. Another useful source of reference is The CFA Guide to Contract Flooring. Subfloors should be sound, smooth, clean, dry and free from any contamination which will affect adhesion. Relative humidity of cementitious subfloors should be 75% or less (when tested by the method described in

BS8203). Direct to earth bases must incorporate an effective damp proof membrane. Underfloor heating must be switched off for 48 hours before and after the installation. Very absorbent surfaces should be primed with Morleys JM1000 Universal Primer.

APPLICATION

For best results a minimum temperature of 18°C (65°F) should be maintained for the installation. An appropriate V notched trowel should be used to apply the adhesive evenly. For most carpets a 2.0mm x 6.0mm or B1 trowel will be suitable. However, for rough backed or ribbed carpet a 3.0mm x 6.0mm or B2 trowel is recommended and for smooth floorcoverings a 1.5mm x 5.0mm or A2 trowel should be used. Trowels should be cleaned after use with water whilst the adhesive is still wet. Apply adhesive evenly to an area of such size that the floorcoverings can be laid whilst the adhesive is receptive and gives good transfer (usually whilst the adhesive is still wet). When installing an impervious floorcovering onto a well sealed subfloor allow the adhesive to develop a slight tack or employ a "double drop" technique to reduce the waiting time before laying. Unless the floorcovering manufacturer recommends otherwise the entire installation should be rolled or weighted glider applied in both directions immediately the installation is complete to remove any trapped air and ensure good adhesive transfer. It may be necessary on some floorcoverings to roll a second time, approximately 1 hour later, to ensure a strong bond is established.

HEALTH & SAFETY PRECAUTIONS

Refer to Material Safety Data Sheet and follow the advice given. Ensure area of use is well ventilated. Avoid prolonged contact with skin and if sensitive, use barrier cream or gloves. In case of contact with eyes, mouth or nose, rinse with plenty of water and seek medical help. If adhesive is spilled, remove and dispose of it in accordance with national and local regulations for waste materials.

morleys
A D H E S I V E S

MORLEYS ADHESIVES (2013) LTD

Unit 20, Higher Walton Mill
Higher Walton, Preston PR5 4DJ
Tel: 01772 626700
Fax: 01772 627372
adhesives@morleys2013.co.uk
www.morleys2013.co.uk